



# DECUS

## PROGRAM LIBRARY

DECUS NO.

8-149

TITLE

CORE WINDOW

AUTHOR

Donald C. Uber

COMPANY

Lawrence Radiation Laboratory  
University of California

DATE

August 7, 1968

SOURCE LANGUAGE

21030

1942-1943



1942-1943

## CORE WINDOW

DECUS Program Library Write-up

DECUS No. 8-149

### OPERATING INSTRUCTIONS

1. Load CORE WINDOW into any Field using the Binary Loader.
  - \* 2. Set the DATA FIELD switches to the Field to be viewed.
  - \* 3. Set the INST FIELD switches to the Field CORE WINDOW was loaded into.
  4. Set the SWITCH REGISTER to 7400.
  5. Press LOAD ADD.
  6. Press START.
  7. Set the SWITCH REGISTER to the address of the First word to be viewed. This setting may be changed at any time.
- \* Ignore if 4K memory is used.



/CORE WINDOW 12/3/68

/SA= 7400

/DISPLAYS 64 CORE WORDS FROM FIELD IN DF SWITCHES

/STARTING AT OCTAL LOCATION IN SWITCH REGISTER.

/AUTO-INDEX REGISTER 17 USED

D=10/SPACE BETWEEN POINTS

T=4000/COLUMN TERMINATOR

TT=6000/CHAR TERMINATOR

INDEX=17/AUTO-INDEX POINTER TO POINT LIST

\*7400

7400	7577	START,RDF
7401	1377	TAD (CDF
7402	3223	DCA DF/STORE DF CHANGE
7403	7577	RIF
7404	1377	TAD (CDF
7405	3206	DCA .+1
7406	7000	NOP/CHANGE DF TO IF SW SETTING
7407	1206	TAD .-1
7410	3225	DCA IF/CHANGE DF BACK AFTER GETTING DISPLAY WORD
7411	7604	FRAME,LAS
7412	3302	DCA ADDR
7413	1311	TAD Y0
7414	3307	LINE,DCA Y
7415	1310	TAD X0
7416	3306	DCA X
7417	1302	TAD ADDR
7420	4241	JMS WORD/DISPLAY ADDR
7421	1315	TAD XTRA
7422	3306	DCA X
7423	7000	DF,NOP/CHANGE DF TO GET DISPLAY WORD
7424	1702	TAD I ADDR
7425	7000	IF,NOP/CHANGE DF BACK TO IF
7426	2302	ISZ ADDR
7427	7000	NOP
7430	4241	JMS WORD/DISPLAY WORD
7431	7510	SPA
7432	5222	JMP DF-1/DISPLAY NEXT WORD
7433	7200	CLA/END OF LINE
7434	1307	TAD Y
7435	1316	TAD LINSPO
7436	7500	SMA
7437	5214	JMP LINE/DISPLAY NEXT LINE
7440	5211	JMP FRAME/START NEW FRAME
7441	0000	WORD,0/DISPLAYS A WORD
7442	3305	DCA DISWRD

IR 7774 AT 7443

7443	1374	TAD (-4
7444	3303	DCA CHRCNT
7445	1305	CHAR,TAD DISWRD
7446	7004	RAL
7447	7006	RTL
7450	3305	DCA DISWRD
7451	1305	TAD DISWRD
7452	7004	RAL
7453	0007	AND (7/AC CONTAINS CHAR.
7454	1317	TAD (TABLE
7455	3304	DCA POINTR
7456	1704	TAD I POINTR
7457	3017	DCA INDEX/POINTS TO CHAR POINT LIST
7460	1313	TAD CHRSPC
7461	1312	COLUMN,TAD PTSPC
7462	1306	TAD X
7463	7577	DXL
7464	3306	DCA X
7465	1307	TAD Y/BASE OF CHAR
7466	1417	POINT,TAD I INDEX/ADD DELTA Y
7467	7577	DYS/DISPLAY POINT
7470	7500	SMA
7471	5266	JMP POINT
7472	7004	RAL/END OF COLUMN
7473	7700	SMA CLA
7474	5261	JMP COLUMN/DISPLAY NEXT COLUMN
7475	2303	ISZ CHRCNT
7476	5245	JMP CHAR/DISPLAY NEXT CHAR
7477	1306	TAD X
7500	1314	TAD WRDSPC
7501	5641	JMP I WORD/END OF WORD
7502	0000	ADDR,0/ADDR OF WORD BEING DISPLAYED
7503	0000	CHRCNT,0/CHAR COUNTER
7504	0000	POINTR,0
7505	0000	DISWRD,0/WORD BEING DISPLAYED
7506	0000	X,0/X-COORDINATE OF POINT
7507	0000	Y,0/BASE OF CHAR
7510	5757	X0,6000-21/INITIAL VALUE OF X
7511	1623	Y0,1623/INITIAL VALUE OF Y
7512	0010	PTSPC,D/SPACE BETWEEN POINTS
7513	0011	CHRSPC,21-D/EXTRA SPACE BETWEEN CHARS
7514	0051	WRDSPC,51/EXTRA SPACE BETWEEN WORDS
7515	0051	XTRA,51/EXTRA SPACE AFTER ADDRESS COLUMN
7516	7703	LINSPC,-75/-SPACE BETWEEN LINES
7517	7526	TABLE,ZERO-1/ORIGINS IN CHAR POINT LIST
7520	7540	ONE-1
7521	7555	TWO-1
7522	7277	THREE-1
7523	7312	FOUR-1
7524	7326	FIVE-1
7525	7343	SIX-1
7526	7360	SEVEN-1



7527	0010	
7530	0010	
7531	0010	
7532	4010	ZERO,D;D;D;D+T/CHAR POINT LIST
7533	0000	
7534	4050	0;D+D+D+D+D+T
7535	0000	
7536	4050	0;D+D+D+D+D+T
7537	0010	
7540	0010	
7541	0010	
7542	6010	D;D;D;D+TT
7543	0000	
7544	4030	ONE,0;D+D+D+T
7545	0000	
7546	4040	0;D+D+D+D+T
7547	0000	
7550	0010	
7551	0010	
7552	0010	
7553	0010	
7554	4010	0;D;D;D;D;D+T
7555	6000	TT
7556	0000	
7557	4040	TWO,0;D+D+D+D+T
7560	0000	
7561	0010	
7562	4040	0;D;D+D+D+D+T
7563	0000	
7564	0020	
7565	4030	0;D+D;D+D+D+T
7566	0000	
7567	0030	
7570	6010	0;D+D+D;D+TT *7300
7300	0010	
7301	4040	THREE,D;D+D+D+D+T
7302	0000	
7303	0030	
7304	4020	0;D+D+D;D+D+T
7305	0000	
7306	0020	
7307	0020	
7310	4010	0;D+D;D+D;D+T
7311	0010	
7312	6040	D;D+D+D+D+TT
7313	0020	
7314	0010	
7315	0010	
7316	4010	FOUR,D+D;D;D;D+T
7317	4020	D+D+T
7320	4020	D+D+T
7321	0000	
7322	0010	
7323	0010	
7324	0010	
7325	0010	
7326	6010	0;D;D;D;D;D+TT
7327	0000	
7330	0030	
7331	0010	

7332	4010	FIVE,0;D+D+D;D;D+T
7333	0000	
7334	0030	
7335	4020	0;D+D+D;D+D+T
7336	0000	
7337	0030	
7340	4020	0;D+D+D;D+D+T
7341	0010	
7342	0010	
7343	6030	D;D;D+D+D+TT
7344	0000	
7345	0010	
7346	0010	
7347	0010	
7350	0010	
7351	4010	SIX,0;D;D;D;D;D+T
7352	0000	
7353	4020	0;D+D+T
7354	0000	
7355	4020	0;D+D+T
7356	0000	
7357	0010	
7360	6010	0;D;D+TT
7361	0000	
7362	0010	
7363	4040	SEVEN,0;D;D+D+D+D+T
7364	0020	
7365	4030	D+D;D+D+D+T
7366	0030	
7367	4020	D+D+D;D+D+T
7370	0040	
7371	6010	D+D+D+D;D+TT



ADDR	7502
CDF	7577
CHAR	7445
CHRCNT	7503
CHRSPC	7513
COLUMN	7461
D	0010
DF	7423
DISWRD	7505
DXL	7577
DYS	7577
FIVE	7327
FOUR	7313
FRAME	7411
IF	7425
INDEX	0017
LINE	7414
LINSPC	7516
ONE	7543
POINT	7466
POINTR	7504
PTSPC	7512
RDF	7577
RIF	7577
SEVEN	7361
SIX	7344
START	7400
T	4000
TABLE	7517
THREE	7300
TT	6000
TWO	7556
WORD	7441
WRDSPC	7514
X	7506
XTRA	7515
X0	7510
Y	7507
Y0	7511
ZERO	7527